+ AUTODOC CLUB


How to change ignition coil on **Mercedes W203** – replacement guide







VIDEO TUTORIAL



i Important!

This replacement procedure can be used for:

MERCEDES-BENZ SLK (R170) 200 2.0 Kompressor (170.444), MERCEDES-BENZ SLK (R170) 230 2.3 Kompressor (170.449), MERCEDES-BENZ C-Class Saloon (W203) C 180 (203.035), MERCEDES-BENZ CLK (C208) 200 2.0 Kompressor (208.344), MERCEDES-BENZ CLK (C208) 230 2.3 Kompressor (208.348), MERCEDES-BENZ CLK Convertible (A208) 200 2.0 Kompressor (208.444), MERCEDES-BENZ CLK Convertible (A208) 230 2.3 Kompressor (208.448), MERCEDES-BENZ C-Class T-modell (S202) C 180 T (202.081), MERCEDES-BENZ C-Class T-modell (S202) C 200 T Kompressor (202.087), MERCEDES-BENZ E-Class Saloon (W210) E 200 Kompressor (210.048), MERCEDES-BENZ E-Class T-modell (S210) E 200 T Kompressor (210.248), MERCEDES-BENZ C-Class Coupe (CL203) C 200 Kompressor (203.745), MERCEDES-BENZ C-Class Coupe (CL203) C 230 Kompressor (203.747), MERCEDES-BENZ C-Class T-modell (S203) C 200 Kompressor (203.245), (+ 2)

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1–9







REPLACEMENT: IGNITION COIL - MERCEDES W203. TOOLS YOU NEED:



- HEX bit No.HW5.
- Drive socket # E8
- Torque wrench

- Flat screwdriver
- High-temperature anti-seize lubricant
- Fender cover

BUY TOOLS

CLUB.AUTODOC.CO.UK 2-9







Replacement: ignition coil – Mercedes W203. AUTODOC experts recommend:

- The replacement procedure is the same for the ignition coils of all cylinders.
- Please note: all work on the car Mercedes W203 should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1

Open the hood.



Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.



Undo the engine cover screws (3 pieces). Use HEX No.HW5.



CLUB.AUTODOC.CO.UK 3–9







4 Remove the engine cover.



5 Detach the connector from the ignition coil.



6 Unscrew the ignition coil bracket. Use a drive socket #E8.



7 Take out the ignition coil from the spark plug well.

8



Treat the ignition coil tip. Use high-temperature grease. Use a flat screwdriver.



CLUB.AUTODOC.CO.UK 4–9







Install the new ignition coil to the spark plug well. Make sure you hear a click indicating that it is locked in place.



Tighten the ignition coil fastening. Use a drive socket #E8. Use a torque wrench. Tighten it to 9 Nm torque.



Plug in the ignition coil connector.

12



Install the engine cover and secure it. Use HEX No.HW5.



CLUB.AUTODOC.CO.UK 5-9







Run the engine for a few minutes. This is necessary in order to make sure that the component operates properly.



- Shut off the engine.
- Remove the fender protection cover.



Close the hood.





VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 6–9



AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR MERCEDES

IGNITION COIL: A WIDE SELECTION

CLUB.AUTODOC.CO.UK 7–9







CHOOSE CAR PARTS FOR MERCEDES W203

IGNITION COIL FOR MERCEDES: BUY NOW

IGNITION COIL FOR MERCEDES W203: THE BEST DEALS & OFFERS

① DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.

CLUB.AUTODOC.CO.UK 8-9